

EVOLVEO Doorphone IK06 - Schéma zapojení

Wiring instructions:

1. Intercom and unlocking wire
2. Ground wire
3. Video wire
4. Power wire
5. Lock +
6. Lock -

